

# SIMPSONS

## - QUICK START GUIDE -

**MODEL: SIMPSONS SUPAJET**  
**TPO: 2600w @ 220/240v - 50/60hz**

### Safety First

Using your Simpsons dryer is easy. Nevertheless, for your own safety and to ensure reliable use, please adhere to the following guidelines.

Please read these operating instructions carefully before using this appliance. Keep these instructions handy for future reference.

### NEVER

- Operate the dryer in the bath or under a shower.
- Immerse the dryer in water or other liquids.
- Operate the dryer if it becomes damaged and/or does not work properly for any reason.
- Attempt to repair the dryer yourself, but apply to the manufacturer or an authorised service agent.
- Clean the dryer with abrasive cleaners, scouring agents, acids or chlorine bleach. These will damage the dryer.
- Operate the dryer without suitable air-filter(s) fitted.
- Switch electricity on or off with wet hands.
- Leave the dryer close to a fire or high temperature heat source. Prolonged exposure may seriously damage the dryer.

### ALWAYS


- Clean and/or replace air filters on a regular basis.
- Disconnect the dryer from the electricity supply when not in use.
- Have the dryer serviced at regular intervals.
- Have the dryer tested annually for electrical safety.

### Electricity Supply

To ensure electrical safety, the dryer must not share plugs or wall sockets with any other appliances. In keeping with health and safety guidelines, do not use multi-way adaptors and use electrical circuit breakers where appropriate. If in doubt seek professional advice.

#### Changing the plug:

If a replacement plug is to be fitted, the wires within the mains lead must be connected to the correct terminals.



Please dispose of the discarded plug safely in order to prevent it becoming a shock hazard.


#### Changing the mains cable:

Should the mains cable ever require replacing, please contact the service department. Direct replacement or longer mains lead are available for a nominal charge. Replacement mains leads must be fitted by a professional qualified electrician.

### How to use your dryer

Operating the dryer is simple.

- 1 Press (0-I) to start the dryer.
- 2 Press (I/II) to increase air temperature.



#### Directional Nozzle:

The dryer is equipped with a detachable directional nozzle to improve styling control whilst drying.

### Maintenance

The Supajet dryer is powered by an induction motor which is rated for continuous use and requires no regular mechanical maintenance.

In order to preserve the exterior finish of your dryer, clean it with a soft lint cloth and a mild detergent spray to remove grime.

Following these instructions should provide many years service from the dryer, however. If the appliance is in regular use, routine servicing is recommended on an annual basis.

### Clutch Assembly

The dryer is fitted with a nylon molded clutch, designed to control the vertical position (angle) of the dryers' nozzle. To ensure the smooth working action on this component, lubricate (sparingly) on an occasional basis with oil spray. Be sure to remove any hair or dust that has accumulated before applying the oil.

### Air Filter

The dryer is fitted with a removable air filter, which prevents dust particles and hair from being sucked in by the fan. If the dryer is in regular use, the air filter must be cleaned frequently. To clean it...

#### Quickly! (daily basis)

Using a vacuum cleaner, simply run the nozzle over the filter area until all the dirt and dust has been removed.

#### Thoroughly! (weekly basis)

Remove the filter guard by turning the central thumb screw in an anti-clockwise direction. Once detached from the dryer housing, remove filter and wash in warm soapy water. After washing, rinse to remove any residue collected, and allow to dry before refitting.

**Never operate the dryer without an air filter. Failure to do so will damage the dryers' heating element.**

**Simpsons of Langley Ltd.**

4 Lakeside Business Units, Block Fen Road, Mepal, Cambridgeshire, CB6 2AY, England  
 Tel: +44 (0)1354 691 830 Email: post@simpsons-online.co.uk

Subject to alterations.